





ACURA ARX-05 LMP2 1/24





ACURA ARX-05 LMP2 1/24


COCKPIT ASSEMBLY





ACURA ARX-05 LMP2 1/24

COCKPIT ASSEMBLY






ACURA ARX-05 LMP2 1/24

BODY ASSEMBLY


Use x4 M2x4mm screws provided





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24



BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24


BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24

BODY ASSEMBLY





ACURA ARX-05 LMP2 1/24

BODY ASSEMBLY

